
## Aniline 5/a

## Order No. CH 20401



imber of Strokes (n) ime for Measurement tandard Deviation tolour Change	::	25 to 5 max. 3 min ± 30 % white —> red
mbient Operating Condition	ns	
emperature bsolute Humidity		15 to 40 °C < 50 mg $H_2O$ / L
eaction Principle		

niline + Furfurol —>	Dianiline derivative of
	Hydroxyglutacondialdehyde

N,N-Dimethylaniline is not indicated.

Ammonia concentrations up to 50 ppm do not interfere, but higher concentrations will cause plus errors.

Before carrying out the measurement the reagent ampoule must be broken. The granular contents must be shaken out of the broken ampoule by gently tapping the side of the tube. The tube must be held vertically with the inlet of the tube up during the measurement.